


No. 5020 5021


Diesel Compression Tester



Item No.	Service Part No.	Description
1	45549	Compression Tester
2	217720	Quick Coupler Fitting
3	310810	Compression Test Adapter
4	310840	Compression Test Adapter
5	47484	Compression Test Adapter
6	217791	B-Engine Injector Adapter
7	310832	Glow Plug Adapter
8	308472	Glow Plug Adapter
9	SKW40412	6 Pt., 3/8 Drive Socket Glow Plug
10	308343	Carrying Case
11	209751	Quick Coupler, Socket Half
12	209750	Check Valve
13	209762	12" Compression Hose With 1/8 NPTF Male Ends
14	206324	Straight Fitting
15	214802	Tee Fitting
16	209749	Bleed Valve
-	48570	Inside Lid Decal
-	62337	Carrying Case Foam Insert

No. 5022


Oil Seal / Wear Ring Installer



Item No.	Service Part No.	Description
1	04-149-3-2B	Wear Sleeve and Seal Adapter
2	11536	Socket Head Cap Screw
3	10215	Hex Nut
4	24837	Forcing Screw Washer
5	04-149-3-1A	Attaching Plate
6	17265	Screw, 5/8-18 x 1

No. 5023


Diesel Injector Seat Cleaner



Item No.	Service Part No.	Description
1	45172	Nozzle Seat Reamer
2	208392	Threaded Sleeve
3	10302	O-ring

No. 5024


Navistar Injector Sleeve Remover / Installer



Item No.	Service Part No.	Description
1	ZTSE2534A	Nozzle Sleeve Installer
2	ZTSE2587A	Nozzle Sleeve Remover

No. 5028

Slide Hammer Puller



Item No.	Service Part No.	Description
1	206437	Reducing Adapter
2	208911	Hammer
3	208912	Shank